



System Touch Panel

- 1. Blank Screens Black out the main system
- 2. Shutdown Access the shut down menu to end class
- 3. Microphones Mircophone volume controls
- 4. Left Left Projector sources
- 5. Right Right Projector sources
- 6. Volume Volume control slider
- 7. Camera Control Camera controls and tracking toggle
- 8. Camera Tracking status indicator

Source Description

PC Left - LEFT monitor Installed Computer content
PC Right - RIGHT monitor Installed Computer content
Laptop- Content from laptop/tablet
connected with HDMI cable

Doc Cam - Document Camera content Wireless - Wireless presentation content

Turn on System

Tap anywhere on the main standby screen

Select a Source

Tap the desired source icon underneath the desired projector
*Note: the desired Audio Souce must be selected on the left Projector

Adjust Volume

Press the "up" and "down" arrows to adjust the system volume Tap the speaker button below to mute and unmute the system

Turn off System

Tap Shutdown icon in upper right corner of interface Tap "YES" when prompted to power off system

USERNAME: GMUCLASS PASSWORD: GMUfall2025

Room System Features

- Two projection screens
- Installed computer
- Document Camera
- · Computer monitor with annotation capability
- Ink2Go (screen annotation software see additional instructions)
- Lavalier and Handheld microphone
- · Presenter tracking camera for web conferencing

For more information, visit the GMU Stearns Center website: https://stearnscenter.gmu.edu