![George Mason University logo]

System Touch Panel

Turn on System

Touch the screen and wait for the screen to power on.

Select a Source

Tap the desired source icon from the center of the interface

Adjust Volume

Press the "up" and "down" arrows to adjust the system volume
Tap the speaker button below to mute and unmute the system

Turn off System

Tap Shutdown ⏻ icon in upper right corner of interface
Tap "YES" when prompted to power off system

1. Blank Screens - Black out the main system
2. Shutdown - Access the shut down menu to end class
3. Camera Control - Camera selection and controls
4. PC - Installed computer content
5. Laptop - Content from laptop/tablet
        connected with HDMI cable
6. Wireless - Wireless presentation content
7. doc Cam - Document Camera content
8. Volume - Volume control slider

USERNAME: GMUCLASS
PASSWORD: GMUspring2026

Room System Features

•Installed computer
•Document Camera
•Wireless presentation (see additional instructions)
•Computer monitor with annotation capability
•Ink2Go (screen annotation softwware see additional instructions)
•Multiple cameras for web conferencing